
Manual Central Filters



Manual filters are used to remove dust from vacuum system convey air prior to passing through the positive displacement blower. Advanced Bulk and Conveying, Inc., supplies the filter on a free-standing frame for floor mounting or with mounting bands for various remote mount installations. When ordering, specify the airline size and configuration of the inlet and outlet (straight or 90 degree elbow).





Airflow Pattern

Air in the side, through the pre-cleaner, then out the end of the air cleaner (upper) portion.

Shown on free-standing frame.

AIRFLOW RESTRICTION - SBG Central Filter

Airflow CFM @ 6" H2O	Filter Model	Filter Element - Extended Life
140	G080010	P18 - 2068
210	G100161	P18 - 2071
300	G120251	P18 - 2033
445	G140261	P18 - 2037
760	G160035	P18 - 2036
600	G160331	P18 - 2031